
Factory default program settings are:

- Units Gallons
- Unfiltered unit
- Flow Meter = Rate Selected
- Filter Capacity = 1250 gallons [4731 liters] for a VersaFilter
- Bottle Count = 0.5L (1 Bottle)
- Flow Rate = 1.2 GPM
- 20 second maximum dispense time



To change the program settings, follow these steps:

Display	Action
00000000	Depress button for 3 seconds to enter into the following menu settings and make changes.
BOTTLES REUSED	Note: at anytime it will exit menu and save settings when idle for 10 seconds (no button
(Home Screen)	press) and revert back to Home Screen.
LTR/GAL	Depress button 3 seconds to change from Gallons to Liters,
GAL	or momentary press to advance to next menu.
UNFILT/FILT?	Depress button 3 seconds to change from Unfiltered to Filtered unit,
UNFILT UNIT	or momentary press to advance to next menu.
FLOW METER?	Depress button 3 seconds to change from Rate Selected to (Flow) Meter Enabled,
RATE SELECTED	or momentary press to advance to next menu. Not included on all models.
SELECT RATE	To change flow rate, momentarily depress button to change whole gallon digit.
1.2 GPM UNIT	Hold button 3 seconds to advance to TENTHS of gallon digit.
	Depress momentarily to change the digit.
	Hold button 3 seconds to advance to the next menu.
RESET 00000000	Depress button for 3 seconds to reset Gallon or Liter count,
GALLON CNT	or momentary press to advance to next menu.
[LTR COUNT]	
FILT CAPAC	Depress button for 3 seconds to change filter capacity to 3000 GAL [11355 liters] for
OF 1250 GAL	Versafilter II or Galaxi green filter,
[4731 LTR]	or momentary press to advance to next menu.
3 sec rule?	Depress button for 3 seconds to switch from 0.5L bottle to 3 sec rule,
0.5L	or momentary press to advance to next menu.
	(The 3 Sec rule increases the bottle count based on a 3 second dispense.)
Reset 00000000	Depress button for 3 seconds to reset (Home Screen) BOTTLES REUSED count,
BOT COUNT?	or momentary press to advance to next menu.
Bot Filler	Depress button for 3 seconds to change maximum dispense time to 10, 20 or 30 seconds,
Set_time: 20 s	or momentary press to advance to next menu.
RUN CAL	Depress button 3 seconds to run calibration again,
AGAIN?	or momentary press to advance to next menu.